





BETAR MINI MOOD-O-MATIC™: RELAX is a **Mood Tone Generator** that emits a low frequency tone associated with the alpha range of human brainwave activity - **wakeful relaxation**. The RELAX Tone – 7.83 cycles per second – is the naturally-occurring frequency of resonance between the Earth's upper atmosphere and the surface of the planet. This **soothing hum** was the dominant background frequency for all living things until the arrival of the “modern” age, when continuous exposure to high energy electrical and telecommunication signals became the norm.

BETAR MINI MOOD-O-MATIC: RELAX provides peaceful, low-intensity stimulation that can **allow the user to remain centered in a positive state of deep relaxation**. The effect is similar to playing soothing music in your home to drown out the noise coming from the busy street outside. The noise outside is still present, but your focus is drawn to the calming music. Because the RELAX Tone is well below the range of normal human hearing, it is generated using the exclusive BETAR dual-spin coil antenna rather than an audio speaker. The result is a tone that may be perceived as a low hum or not at all. Many users describe a “wave of calm” settling into the room when their Mood Tone Generator is activated.



INSTRUCTIONS

POWER: This device is designed to utilize 9 volts of direct current (DC) electricity at 500 milliamps. Units purchased in the USA include a transformer that delivers the appropriate power. International users should purchase a transformer designed for use with the local electrical system. Be certain to select a unit with a positively-charged internal tip delivering 9 volts of direct current (DC) power at 500 milliamps. As per this diagram, the connector should have a 5.5 mm external sleeve and a 2.1 mm internal sleeve.



ACTIVATE: To activate the Mood Tone Generator, first plug the power supply tip into the jack found on the rear of the unit, then plug the transformer into the wall outlet. *Failure to complete this step in the correct order may damage the device.* To turn on the emitter, move the silver toggle switch on the front of the device from right to left. Because the RELAX Tone is below the range of human hearing, most users perceive the tone as a low hum or not at all. The LED indicator will blink when the unit is turned on and receiving power.



EFFECTIVE RANGE: The Mini Mood-O-Matic Mood Tone Generator has an effective range of approximately 10 feet (3 meters) in any direction. However, because the signal fades as the distance between the emitter and the user increases, **keep the device close by** for maximum benefit.

USE: **BETAR MINI MOOD-O-MATIC: RELAX** is intended for use whenever wakeful relaxation is desired, including the home, office or automobile.

THE BETAR GUARANTEE

Like all BETAR products, the **BETAR MINI MOOD-O-MATIC: RELAX** is covered by our **100% satisfaction guarantee**. Send your unit back undamaged within 30 days and we will refund your money, no questions asked.

www.betar.com